


## Testing procedure:

1. connect a Laptop with IP 192.168.20.1 to Internet Router 1



- 2.1. ping 193.156.3.**235** (if success, you see our router)  
**note** down the ping time: x ms
- 2.2. Open Web browser to: 193.156.3.**236** (you should see: Basic Internet ... Welcome)
- 2.3 Open Web browser to: 193.156.3.236/login.php (you should get the Yamboo login page)